

# iLED6

## Zoom ENG LED Light QUICKSTART GUIDE



### What's included

- iLED6 Light
- AC Adapter 1.2A
- Sony "L" DV Battery
- DV Battery Charger
- Shoe Mount



### CONDITIONS OF WARRANTY SERVICE


- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- The components and maintenance service fee will be charged if the warranty period has expired.

Free Service will not be Provided in the Following Situations: (\* Even if the product is still within the warranty period.)

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company.
- Damage caused by natural disaster, abnormal voltage, and environmental factors etc.

# iLED6

## Zoom ENG LED Light QUICKSTART GUIDE



### SPECIFICATIONS

Type:	Zoom LED Light
Power Consumption:	6W
Color Temperature:	Daylight
Voltage:	7V-18V
Weight (lb):	0.41
Weight (kg):	0.19
Dimensions (in):	7.33 L x 2.65 W x 2.65 H
Dimensions (cm):	18 L x 6.5 W x 6.5 H

### GETTING STARTED

1. The iLED6 can be powered by the included AC adapter or the Sony L Series DV battery.
2. Turn the light on by twisting the Dimmer Knob clock-wise when you hear a “click”. Vice versa, turn the light off by twisting the Dimmer Knob counter clock-wise until you hear a “click”.
3. The Dimmer Knob allows you to adjust the intensity of the light. Adjust the intensity of the light by turning the Dimmer Knob clock-wise to increase the intensity and counter clock-wise to reduce it.